SANUPS A11N / A11N-Li Series Checking the UPS Revision Number

- When downloading the instruction manual, download the instruction manual corresponding to the UPS revision number.
- The UPS revision number can be checked with the rating plate or the model name label on the UPS.
  The alphabet at the end of the number indicated in “SERIAL No.” on the rating plate or “S/N” on the model number label attached at the position shown in the figure below is the UPS revision number. The same serial number is indicated on both labels.



Rating plate (Example)





Model Number Label (Example)



Note

The alphabet in position **(2)** of “SERIAL No.” and “S/N” is the UPS revision number.

The “U” or “P” at the end of (1) is the factory identification code.
Be careful that it is not the UPS revision number.

11 digits + Factory identification code

SERIAL No. xxxxxxxxxxxU A

(1) **(2)**

Factory identification code **Revision No.**